





BOUTONS




Batterie: CR2025

LUMINEUX




Affichage de contre-jour 3 secondes


SÉLECTION MODE




ALARM




CHRONOMÈTRE




DUEL DES TEMPS




CHRONOMÈTRE




DECOMPTAGE



PACER




КНОПКИ




ПОДСВЕТ




ВЫБОР МОДЕЛИ




СИГНАЛИЗАЦИЯ



ХРОНОМЕТРИРОВАНИЕ




ДВОЙНОЕ ВРЕМЯ




СЕКУНДОМЕР




ОБРАТНЫЙ СЧЕТ ВРЕМЕНИ




ПРИХОДЕЦ




TASTI




Retroilluminazione




MODALITÀ DI SELEZIONE




ALLARME




Cronometro




DUALTIME




CRONOMETRO



COUNTDOWN




PACER




按鍵功能




冷光




模式選擇




鬧鈴




時間




第二時間



腕表



倒計時



節拍器

